






IL SYSTEM INTEGRATOR
THE SYSTEM INTEGRATOR







3B6®



**Display
Displays**



**Sensori
Sensors**



VT3 è un potente software per il controllo delle unità e dei display programmabili COBO. Usando VT3, l'utente programmatore può:




1. Sviluppare la logica di controllo del software applicativo secondo IEC 61131
2. Definire i messaggi CAN-BUS per la comunicazione con altri dispositivi
3. Definire la configurazione dei segnali di input e output
4. Usare 4 differenti linguaggi di programmazione: FBD, LD, ST, "C/C++"
5. Avere uno strumento per display grafici WYSIWYG

VT3 is a powerful tool for the control of COBO programmable units and displays. With VT3 the developer can:

1. Program controllers using IEC 61131 standards
2. Define CAN BUS data for network communication
3. Define I/O mapping
4. Use 4 different programming languages: FBD, ST, LD, "C/C++"
5. Have WYSIWYG display graphic tool






IL FORNITORE DI SOLUZIONI COMPLETE
THE COMPLETE SOLUTION PROVIDER



Centraline e Controlli Globali
Main Units & Global Controls



Accessori e Altre Interfacce
Accessories & Other Interfaces



winloader

- Programma per il caricamento sul device del software applicativo
- *Application software download tool*



winscope

- Programma per il caricamento esalvataggio su PC dei parametri applicativi (CAN e RS232)
- Visualizzazione e scrittura delle variabili di diagnostica in funzione dei livelli di accesso utente
- Forzatura dei valori di I/O
- Gestione livelli di accesso utente
- Integrazione con "winloader" ed "e.log viewer"



e.log viewer

- Programma per il download e visualizzazione dei dati del Datalogger
- *Datalogger download and visualization tool*

- *Tool for upload/download controllers parameters via CAN BUS or RS232*
- *Reading and writing variables in real time (according to user level)*
- *I/O forcing by user for diagnostic*
- *Different access levels management*
- *Integration with "winloader" and "e.log viewer"*



Headquarters:

Via Tito Speri, 10

25024 Leno (Brescia) ITALY

Phone +39 030 90451

Fax +39 030 9045330

info@cobospa.it

www.cobospa.it



C.O.B.O. S.p.A. - Divisione 3B6

Via Sivo, 74

28053 Castelletto Sopra Ticino (Novara) ITALY

Phone +39 0331 9286.1

Fax +39 0331 972160

3b6@3b6.it

www.3b6.it